

Selecting the Face Driver components:

- **#1** Determine the Face Driver model with the type of mounting required for the machine.
- #2 If mounting directly to machine spindle, verify spindle size and select appropriate spindle adapter.
- #3 Choose the center point with the diameter range closest to the center hole diameter.
- #4 Determine machine spindle rotation and driving diameter to select the correct drive pins.
 - Rotation is determined by looking directly at the spindle face or chuck face.

(For detailed instructions on selecting a face driver, see page 51).






Morse Taper*



Flange Mount*

* All mechanical styles can be chucked.

#1 FACE DRIVER					
Order Code	Mounting Style				
5006	#6 Morse Taper*				
50FM	Flange Mount*				



* All mechanical styles can be chucked.

#3 CENTER POINT		#4 DRIVE PINS (6 pins required)					
Order	Center Hole	Order Code	Counterclockwise (Right) Outer Driving Inner Driving		Clockwise (Left) Outer Driving Inner Driving		
Code	Dia. Range	Coue	Diameter	Diameter	Diameter	Diameter	
C5101	0.120 - 1.380	P5001	4.33	3.94	-	-	
C5102	1.339 - 1.575	DEOOO			4.00	0.04	
C5103	1.535 - 1.772	P5002	-	-	4.33	3.94	
C5104	1.732 - 1.969	P5003	4.92	3.94	-	-	
C5105	1.929 - 2.165						
C5106	2.126 - 2.362	P5004	-	-	4.92	3.94	
C5107	2.323 - 2.559	P5005	5.51	4.73**	_		
C5108	2.520 - 2.756	1.2003	5.51	4.75			
C5109	2.717 - 2.953	P5006	-	-	5.51	4.73**	

** Half chiseled edges for better gripping

TO ORDER: A complete unit consists of a face driver, center point and drive pins. For direct mounts, a spindle adapter must be added.

- #1 Face Driver order code: _ _ _
- **#2 Spindle Adapter** order code: _____ (only required for direct mount)
- #3 Center Point order code: _ _ _ _ _
- #4 Drive Pins order code: _ _ _ _ (6 pins required)